PMT

- Group IIC

weather

- Zone 1, 2, 21, 22

Earthing pliers

- Robust and easy to handle

- Safe and reliable over time

- High resistance to corrosion and extreme

Non-slip grip

Contacts in phosphorous bronze

Optimum resistance to wear and corrosion

Metal plate




PMT Earthing pliers

The PMT pliers are used to connect tankers and tank trucks to ground during loading and unloading operations. The ground contact occurs inside the body of the pliers in an Ex d chamber, only after the pliers have been connected to the local earthing system.

Cortem Group applies a tamper-evident holographic security label to its products, complete with a unique authentication numeric code, to combat the illegal sale of imitations and counterfeits, as well as guarantee the authenticity of its products. Failure to observe international standards creates serious risks for the environment and, above all, for the personnel who work with the systems on a daily basis.







ATEX Certificate





Use and maintenance instructions

PMT Earthing pliers



MECHANICAL FEATURES


External contact elements: Certificate label: Screws, bolts and nuts:	In black non-slip rubber In phosphorous bronze Riveted aluminium on the grip Stainless steel
Cable gland:	For non-armored cable, thread ISO M32

ELECTRICAL FEATURES


Isolating voltage:	3 kV
Rated current:	20 A

SELECTION TABLE

Code	Cable range	Connection plate thickness	Weight Kg
PMT-B2	Ø 11 - 14	4 - 7	0.8



DIMENSIONAL DRAWING



Dimensions in mm



